



# M.D. STETSON

## FIBERMASTER DEFOAMER

### RECOVERY TANK FOAM ELIMINATOR

Add **Fibermaster™ Defoamer** concentrate to the recovery tanks of extraction equipment, auto-scrubbers, wet vacs and other powered equipment to eliminate foam build-up that can interfere with the equipment's solution recovery operation. The use of **Fibermaster™ Defoamer** concentrate in the recovery tank will result in greater equipment efficiency.

#### DIRECTIONS FOR USE

Shake before using.

Add 2 ounces of **Fibermaster™ Defoamer** concentrate to the recovery tank before beginning the extraction operation.

For best results, vacuum up **Fibermaster™ Defoamer** solution with the machines vacuum hose into the recovery tank. This allows the solution to coat the tank and hose.

Never use **Fibermaster™ Defoamer** concentrate in the solution tank

#### SPECIFICATIONS

Appearance ..... White turbid liquid  
 Fragrance ..... None  
 pH..... 8.5-9.5  
 Specific gravity..... 0.99-1.01  
 Storage stability ..... 1 year

**Refer to the Safety Data Sheet (SDS) for detailed safety, health and environmental information.**

#### PACKAGING

Available in 1 gallon plastic containers.

May 2017